

# THE BUS+ D-EQ Setting





Press & Hold

## D-EQ RANGE RIGHT side





## D-EQ Frequency Points LEFT side

LF



HF



HF  
BELL

